



Introduction to Your Atlas

Navigation

Driver Assistance Features

Climatronic System

Bluetooth® / Voice Recognition

TPMS / Keyless Access / Parking Brake / myVW

Wipers / Luggage Compartment Lid / Memory Seats



The information within this guide must be used in conjunction with the information in the Volkswagen Owner's Manual, You should refer to your vehicle's Owner's Manual and Infotainment System Booklet for all information and warnings, and feature limitations. Always pay careful attention to the road and do not drive while distracted. Some Infotainment features can only be accessed and operated when the vehicle is standing still.

1. Digital Cockpit/Instrument Cluster

Displays vehicle system and function information.
Digital Cockpit Display Options can be accessed using the multi-function steering wheel controls and can be customized using the infotainment screen.

Touch-sensitive buttons control the various Infotainment functions, including radio, media selections, App-Connect functions, phone operation, vehicle functions and the optional Navigation system.

3. Start-Stop System
When the light is off, the system is activated. System is deactivated when the light is on. Start-stop is automatically activated when the light is on. Start-stop is mutomatically activated when the lightion is switched on. For more information, see operating conditions in Owner's Manual.

4. USB Port*

The USB port(s) in the center console, marked with a will transfer data and charge your device. The USB port(s) in the rear are a charge-only connection.

Driving Mode Selection (not shown)
 Driving mode selection offers a choice of Snow, Onroad,
 Offroad and Custom Offroad. AWD vehicles offer additional
 driving modes in the Onroad driving mode selection menu.

6. Luggage Compartment Lid* (not shown)

Pull on this switch to open the luggage compartment lid.
When the ignition is on and the vehicle is in Park, pull and hold this switch to close the lid. If your vehicle is not equipped with the luggage compartment lid, this button will unlock the trunk lid.

7. Steering Wheel Left Side Controls Buttons for operating the Cruise Control or Adaptive Cruise Control* and Driver Assistance features. Volume settings for radio, Navigation system notifications or phone calls.

8. Steering Wheel Right Side Controls

Voice Control Button: Activates the Voice Recognition System. Short press to activate Volkswagen Voice Control,* long press to activate third party voice control with a compatible smart phone connected to App-Connect.

VIEW Button: For vehicles with Digital Cockpit,

VIEW

VIEW Button: For Venices with Digital Cockpit, switches between wide and standard display.

OK Button: Used to select settings for features in the instrument cluster display.

Horizontal Menu Buttons: Used to navigate through the instrument cluster's main menus.

Vertical Arrow Buttons: Push to navigate inside a

Horizontal Arrow Buttons: Push to change radio stations, scroll through radio presets or select the next MM

or previous media track.

Steering Wheel Heating: Activates the heated steering wheel. Can be pressed repeatedly to select between three levels of heating and held for one second to save a heating level. Press and hold to recall the last saved level. Press repeatedly until bar display in instrument panel goes out to turn off.

9. Remote Start* (not shown)
If your vehicle is equipped with this feature, the engine can
be started from outside the vehicle with the Remote Start
button, allowing the HVAC system to heat or cool the interior.
On your key fob, press the Lock button, then the Remote Start
button (2) twice. Pressing three times will cancel operation.
Remote Start can also be activated in the VW Car-Net app.

10. Wireless Charging
Can charge a Qi-capable mobile phone without the need to plug in a cable. Simply place it in the center of the surface with the display facing up. The charging process starts automatically. Available on sel

Introduction to Your Atlas

Navigation

Driver Assistance Features

Climatronic System

Wipers / Luggage Compartment Lid / Memory Seats

Bluetooth® / Voice Recognition

Discover Media Touchscreen Navigation System

- 1. Press the NAV hutton
- 2. Select New destn. on the touchscreen.
- 3. Begin entering a Point of Interest (POI) or address information starting with House number, Street, City.
- 4. When your POI or address appears, touch the correct address on the screen.
- 5. Select Start to begin route calculation.

Applies to vehicles equipped with Navigation feature. When entering an address for another state, use only the two-character abbreviation for the state. Entering a destination on the touchscreen or changing any settings can only be done when the vehicle is stationary. The navigation SD card must be in one of the Media Box SD card slots.

Additional Settings

To include alternative routes and make additional navigation customizations, select route options prior to starting route guidance. Here you can:

- Choose between three alternative routes if available.
- Use Dynamic route guidance if SiriusXM® Traffic* is available.
- Avoid certain road types and more.

*Always pay careful attention to the road, and do not drive while distracted. SiriusXM audio and data Aways pay carein attention or the rote, and or not other within estate, etc., Shitsawa addit and data services each require a subscription sold separately, or as a package, by Sirius XM Radio Inc. If you decide to continue service after your trial, the subscription plan you choose will automatically renew thereafter and you will be charged according to your chosen payment method at then—current rates. Fees and taxes apply, To cancel you must call stirriss/M at 1 + 666 - 635—249. See Sirriss/M Customer Agreement for complete terms at www.siriusxm.com. All fees and programming subject to













Text NAV6-21 to 38981 to watch the Navigation: Manual Destination video. Always pay careful attention to the road, and do not text and drive. Message and data rates apply.

Points of Interest (POI)

- 1. Press the NAV button, then select POIs on the touchscreen to choose the most common POI types for your travels.
- 2. Select Start to begin route guidance.

Note: The navigation SD card must be in one of the Media Box SD card slots.

Cancel Active Route Guidance

- 1. Select Route on the touchscreen.
- 2. Select Stop route guidance option on the touchscreen.

Alternative Navigation

Turn-by-turn directions are also available by mirroring your favorite compatible smartphone app to your infotainment screen. Using the maps app on your device, you can connect to Volkswagen App-Connect by using a manufacturer-approved cable to your vehicle's USB port.



Text NAVPOINT6-21 to 38981 to watch the Navigation: Point of Interest video. Always pay ca attention to the road, and do not text and drive. Message and data rates apply.

Marnings: See Navigation in your Owner's Manual for more detailed information and for important safety warnings. Navigation is an optional feature.

Navigation

Driver Assistance Features

Climatronic System

Wipers / Luggage Compartment Lid / Memory Seats

Bluetooth® / Voice Recognition

Activate Cruise Control

Locate the Cruise Control buttons on the left side of the multi-function steering wheel.

- Press the O/I button to activate Cruise Control.
- A speedometer icon will appear in the instrument cluster display.

Set Cruising Speed

- 1. When you reach your desired cruising speed, press the SET button on the multi-function steering wheel.
- 2. A green cruise control indicator light 🔭 will illuminate in the instrument cluster display.
- 3. To increase/decrease the speed by 1 mph increments, press and release the + or - button.
- 4. To increase/decrease the speed by 5 mph increments, press and hold the + or - button.

Cancel and Resume

- 1. To cancel the cruise speed, press the brake pedal or press the 6/1 button once on the multi-function steering wheel.
- 2. The green CRUISE indicator light will go off. Your last selected speed stays in memory until you turn off the ignition or turn Cruise Control off.
- 3. To resume your set speed, press the RES button on the multi-function steering wheel.

Turning Cruise Control System Off

Press twice.



Traffic Jam Assist

This feature is not a substitute for attentive driving. See the Owner's Manu for further details and important limitations. Applies to vehicles equipped w Traffic Jam Assist feature.

Traffic Jam Assist helps the driver stay in the lane and drive in traffic jams or stop-and-go traffic. Traffic Jam Assist is automatically enabled if the following conditions are met:

- Lane Assist must be switched on together with adaptive lane guidance and must be active.
- Adaptive Cruise Control (ACC) must be switched
- The selector lever must be in the D/S position or in the tiptronic shift gate.
- The speed is less than 37 mph (or 60 km/h).




Text CRUISE6-21 to 38981 to watch the Cruise Control video. Always pay careful attention to the road, and do not drive while distracted. Message and data rates apply.

Adaptive Cruise Control

Adaptive Cruise Control (ACC) helps maintain an individually stored constant speed and a previously set distance between your vehicle and those in front of you. When you approach a slower moving vehicle in front of you, the vehicle may brake if the situation requires. When the vehicle is no longer present, ACC will accelerate back to the stored speed. You can set the speed-dependent distance from the vehicle ahead to one of five levels.

- When the ACC button is pressed to activate ACC, the 😝 indicator light illuminates in the instrument cluster.
- To change the ACC distance interval, press the button to cycle through the distance intervals. When the shortest interval is reached, the distance returns to the greatest interval when the button is pressed again.
- When the Adaptive Cruise Control system brings the vehicle to a stop, briefly press the accelerator pedal or press **RES** on the multi-function steering wheel to resume Adaptive Cruise Control.

If your vehicle is equipped with Driver Assistance features,




you can access and customize them in the Assistance system settings menu of the Infotainment system.

- 1. Select CAR function.
- 3. Select Assistance system i.e. (lane assist, collision avoidance, Blind Spot monitor, etc.).

Disabling Park Distance Control Audible

The audible tone from the Park Distance Control System can be disabled by pressing the P button on the center console. The warning will reactivate automatically when the reverse gear is engaged or the button is pressed again.





Text ADAPTIVE6-21 to 38981 to watch the Adaptive Cruise Control video. Always pay careful attention to the and do not drive while distracted. Message and data rates apply.



Warnings: See Driver Assistance Systems in your Owner's Manual for more detailed information and for important safety warnings

Driver Assistance Features

Climatronic System

Wipers / Luggage Compartment Lid / Memory Seats

Bluetooth® / Voice Recognition

Heating and Air Conditioning

- To cool or warm the occupant compartment automatically, press the AUTO button to turn the system on.
- Adjust the driver's temperature dial to your preferred setting.
- Press the SYNC button to synchronize the temperatures between the zones. If there is a large temperature difference between the two zones, it may hamper the system's ability to quickly cool the interior
- In extreme heat, press the MAX A/C button. When a comfortable temperature is reached, press the AUTO button.
- Text CLIMATE6-21 to 38981 to watch the Automatic Climate Control video.



Defrost/Defog 0

- 1. Press the Defrost button. It is recommended to turn the temperature setting to HI for quickest defrost/defogging.
- 2. The A/C function comes on automatically and it is recommended to leave A/C on to dry the air.
- 3. When the windshield is clear, press the AUTO button.
- 4. Side view mirror heating turns on automatically when the front Defrost button 🍿 is pressed and outside temperatures are below +68°F (+20°C).

Note: In the event of significant fogging, opening a win

- 1. Select your preferred temperature with the left temperature dial.
- 2. Adjust the fan speed and vents if necessary.
- 3. Press the SYNC button. The light inside the button will illuminate to show it is active.

Air Distribution 3

The Air Distribution button directs air to the floor, panel or defrost vents or a combination of vents. Pressing the button multiple times toggles through the different airflow settings.

AUTO 0

AUTO allows you to regulate and maintain the occupant compartment temperature at a desired level automatically.

- 1. Turn the driver side temperature dial to the desired temperature.
- 2. Press the AUTO button if it is not already illuminated.

Seat Heating/Ventilation 6

- To warm up quickly on a cool morning, press the 🐗 button for seat heating.
- To cool down quickly in warm weather, press the 🐉 button for seat ventilation.

OFF 6



Turn the fan dial counter clockwise until it stops, and all lights on the dial are off. Or, alternatively you can:

- 1. Press the MENU button on the center control knob.
- 2. Tap OFF on your touchscreen.

Opening and Closing Air Vents

Some of the air vents are adjustable, so passengers can create their own comfortable experience. To clo driver vent, turn the center air control lever all the way to the right. To close the front passenger vent, turn the center air control lever all the way to the left.



Marnings: See Climate Control in your Owner's Manual for more detailed information and for important safety warnings

Climatronic System

Wipers / Luggage Compartment Lid / Memory Seats

Bluetooth® / Voice Recognition

Windshield Wipers and Washer

Intermittent

- From the OFF position, move the wiper stalk one click up to activate the intermittent wipers with rain-sensing.
- The switch on top of the stalk varies the time interval between each wipe.
- The farther the switch is moved to the right, the shorter the interval between each wipe.

Note: Ensure wiper stalk is in the OFF position

Rain-Sensing Wipers

To activate and deactivate using the Infotainment touchscreen:

- 1. Select CAR then select Settings.
- 2. Select Mirror and wiper settings.
- 3. Select Automatic wiper during rain. A check mark indicates it is active.

Continuous

- LOW: From the OFF position, move the wiper stalk up two clicks.
- HIGH: From the OFF position, move the wiper stalk up



Rear Wiper

To operate, push the lever one click away from you. If you have the front wipers on and you put the car in Reverse, the rear wiper activates a single wipe.

Service Position

With hood closed and ignition off, press and hold the windshield lever down. Wipers will move into the service position. Lift wiper arms up from the windshield. Before driving, fold wiper arms back onto the windshield. Turn ignition on, and press the wiper lever down briefly. Wipers move back to the Park position.



Text WIPERS6-21 to 38981 to watch the Windshield Wipers video. Always pay careful attention to the road, and do not drive while distracted. Message and data rates apply.

Luggage Compartment Lid

Setting the Open Position

The opening height of the rear hatch can be adjusted.

- While the rear hatch is opening, press the Luggage Compartment Lid button on the remote key fob to stop it at the desired height. You may also stop it by pressing the button on the rear hatch.
- 2. Press and hold the on the rear hatch edge until the rear lights blink and a tone is heard.
 - The opening height of the rear hatch can be readjusted to the maximum height by pushing upward on the rear hatch and then repeating Step 2.

Easy Open Sensor-Controlled Luggage **Compartment Lid**

lled Luggage Compartment Lid feature.

- You must be carrying your vehicle key on your person, e.g., in your pocket, hand or purse.
- The ignition must be off.
- Quickly move your foot and shin as close to the bumper as possible (in kicking motion) without contacting the bumper. Your shin must be in the upper part of the sensor's range and your foot in the lower part.
- Quickly move your shin out of range. The rear hatch opens automatically.





Text TRUNK6-21 to 38981 to watch the Easy Open Trunk video. Always pay careful attention to the road, and do not drive while distracted. Message and data rates apply.

Memory Seats

Saving Seat Position to Memory

- 1. Adjust the driver's seat and outside mirror positions to your preferred positions then press and release the SET butte
- 2. Press and hold the memory button 1, 2 or 3 until the chime sounds

Recalling Stored Memory Settings

With the vehicle stopped and the ignition ON, press and hold the corresponding memory button.

 With the ignition off and the driver's door open, press and hold the memory button until the stored position is reached.

Text MEMORY6-21 to 38981 to watch the Memory Seat video. Always pay careful attention to the road, and do not drive while distracted. Message and data rates apply.

LEARN MORE AT knowyourvw.com

teld Wipers in your Owner's Manual for more detailed information and for important safety warnings

Warnings: See Trunk Lid in your Owner's Manual for more detailed information and for important safety warnings.

Wipers / Luggage Compartment Lid / Memory Seats

Bluetooth® / Voice Recognition

Pairing a Compatible Phone

- Be sure to check your phone's compatibility at www.knowyourvw.com/bluetooth.
- With ignition on and vehicle in Park, turn the Infotainment system on. Your vehicle's Bluetooth system will be in "discovery" mode.
- From the Bluetooth menu on your phone, search for new devices and select VW BT XXXX (last four digits of VIN).
- A connection request will appear on the Infotainment display.
- 5. Press Connect on the Infotainment display.
- 6. The Infotainment display will then show a PIN.
- Make sure the same PIN is displayed on your phone and press Yes on the Infotainment touchscreen, then press Pair on your phone.

note: If your phone displays a prompt asking to connect to your vehicle, make sure to enable future automatic connections. This will help to automatically reconnect the compatible paired device to the system. Once the PIN is shown, pairing must be completed within 30 seconds; otherwise, the process will need to be repeated.

Primary and Secondary Phone Functionality

Two active phones can be connected simultaneously. Follow steps 1-7 above. Only contacts from the primary phone will be shown within the Infotainment system. Switching between phones requires pressing the **Swapping** icon

vote: This reactive is not available when the phone is connected to Apple CarMay* of Android Auto™.



Text PAIR6-21 to 38981 to watch the Phone Pairing video. Always pay careful attention to the road, and do not drive while distracted. Message and data rates apply.



Call by Name

Topico to remoto wan voice necognition reactive.

- Short press the Voice Control button On the multi-function steering wheel.
- 2. After the chime say "Call," followed by the name of the person you want to call. For example, "Call Mike Brown."
- 3. The system will confirm, "Do you want to call Mike Brown?" You then reply, "Yes." If the contact has multiple numbers, select or say the desired line number on the screen when prompted. Once selected, the system will then say, "Contact is being dialed."
- Text VOICE6-21 to 38981 to watch the Making a Call Using Voice Recognition video. Always pay careful attention to the road, and do no drive while distracted. Message and data rates apply.

Voice Recognition Tips

- The contact must be said exactly as it is stored in your phone's contact list.
- If multiple numbers are stored per contact, you may use the shortcut "Call John Smith work," or the system may ask you to choose, e.g., work, mobile, home, etc.

Answer an Incoming Call

The Bluetooth system will interrupt your car stereo with a ringtone. Press the OK button on the multi-function steering wheel or the green **Phone** icon on the Infotainment touchscreen to answer the call.

Volume Settings

To adjust the volume of the Bluetooth system while on a call, press the **Volume Up** or **Volume Down** button 🔟 💆 on the left side of the multi-function steering wheel.

Switch to Private Mode

To switch a Bluetooth call to your mobile phone, which would prevent passengers from hearing the conversation:

- 1. Once a call has been answered, use the Horizontal Menu buttons 🛫 on the multi-function steering wheel to access the Phone menu in the instrument cluster display.
- **3.** To select, press the **OK** button on the multi-function steering wheel.



End a Call

Press the red **Phone** icon \mathscr{C} on the Infotainment touchscreen. Or, alternatively:

- Use the Horizontal Menu buttons on the multi-function steering wheel to access the Phone menu in the instrument cluster display.
- 2. Press the Vertical Arrow buttons $\stackrel{\triangle}{\bigtriangledown}$ until "End" appears in the instrument cluster display. Press the OK button on the multi-function steering wheel.

Cancel Active Voice Recognition

Double press the **Voice Control** button \bigcirc on the multi-function steering wheel.

Destination Entry

Applies to vehicles with Voice Recognition feature

- 1. Press the Voice Control button \bigcirc on the multi-function steering wheel. A beep will sound.
- 2. Say "New destination."
- 3. After the beep, speak the address; for example "Two zero two four Main Street, Los Angeles." Speak in single digits.
- 4. The system will repeat the address for confirmation and ask if you would like to start route guidance. After the beep, say "Yes" and guidance will begin.



Bluetooth® / Voice Recognition

Tire Pressure Monitoring System (TPMS) Recalibration

The TPMS must be recalibrated each time the tire pressure in one or more tires has been adjusted or after one or more tires has been replaced, rotated or repaired. After longer trips and different vehicle speeds, the system adapts to the new values and monitors them. To recalibrate the TPMS:

- 1. Turn the ignition ON.
- 2. Press the Menu button then press Vehicle menu in the infotainment system.
- 3. Select Settings.
- 4. Select Tires then select Set.
- 5. Select Confirm to store.





Text TPMS6-21 to 38981 to watch the TPMS VICO. Always pay careful attention to the road, and do not text and drive. Message and data rates apply.

Keyless Access

Unlock

- Make sure you have your key fob with you.
- 2. Slide hand behind door handle and wait for the door to unlock. Remember to avoid touching the indent on the front of the handle or the door will remain locked.
- 3. By touching the unlocking sensor twice in a row, the entire vehicle will unlock.
- 4. Pull the handle to open door.

Lock

- 1. Make sure you have your key fob with you.
- 2. Touch your thumb to the lock depression on the handle.

Customize which Doors to Unlock with Keyless Access

- 1. Turn the ignition on and place the vehicle in Park. The vehicle will not allow you to customize Keyless Access while driving. 2. Select CAR from the Infotainment touchscreen.
- 3. Select Settings.
- 4. Select Open and close settings.
- 5. Select Unlock doors and select which doors to lock or unlock with keyless entry.
 - "All doors" unlocks all doors. "Single Door" unlocks only the driver's door.
 - "Vehicle side" unlocks the doors on the driver's side of
 - the vehicle.

✓ All doors Unlock doors: Single door Vehicle side



Text KEYLESS6-21 to 38981 to watch the Keyless Entry video. Always pay careful attention to the road, and do not text and drive. Message and data rates apply.

er's Manual for further details and important warnings about the keyless ignition feature. Do not leave vehicle unattended with the engine running, particularly in enclosed spaces, and consult local laws for any limitations on use

Using the Electronic Parking Brake

Switching the Parking Brake On

When the vehicle is stationary, pull up on and hold the (P) switch to engage the parking brake. The parking brake is activated when a yellow LED light illuminates on the (P) switch and PARK appears in the instrument cluster display. The electronic parking brake will automatically activate if the vehicle is traveling under speeds of about 2 mph, or the driver door opens.

Turning the Parking Brake Off With the vehicle's ignition on, press the brake pedal and

press the (P) switch. OR

When the engine is running, press the accelerator pedal lightly without pressing the brake pedal. The red indicator light will go out when the electromechanical parking brake is no longer engaged.



Text ELECTRONIC4-21 to 38981 to watch the Electronic Parking Brake video. Always pay careful attention to the road, and do not text and drive. Message and data rates apply.

myVW

All things VW. All in one place.

Put essential tools and information at your fingertips. Enjoy features such as:

- Service reminders¹, scheduling & history²
- Maintenance schedules
- Roadside assistance requests³

Plus, get remote features4 and more when you activate VW Car-Net®:

- Remote start⁵ & lock/unlock⁶

myVW Enrollment Process (if not performed by dealer): 1. Download the myVW app

- 2. Click "Sign up" and enter your email and a password
- 3. You'll get an email; click on the link
- 4. Follow the steps to set up your account
- 5. If you do not see your car in the app:
 - · Enter the VIN found on the driver's side of the dashboard
 - Scan a QR code or enter a registration number from your infotainment screen. To find these, go to Menu > Settings > VW Car-Net online services > Registration
- 6. Create a 4-Digit PIN
- 7. Activate VW Car-Net to enjoy remote features1

To learn more about myVW go to vw.com/owner




- Conditions for details.

 Service history is available as long as work was performed since after January 2014 at a participating Volkswagen dealership.

 Roadside Assistance provided by a third party. May require additional payment for services rendered. See owner's literature for limitations and details.

 Available on most MY20 and newer vehicles. Always pay careful attention to the road and do not drive while distracted. Certain services require trial or paid subscriptions, which may have their own terms and conditions. WY Car-Het Remote Access requires a W ID, myWW app, and myWW account, cellular connectivity, network compatible hardware, availability of vehicle GPS signal, and acceptance of Terms of Service. Not all services and features are available on all vehicles and some features may require the most recent software update. Cartain Car-Het services, such as Roadside Call Assist, connect out to 3rd part providers that may require additional paids and data rates may apply for app and web features. See Terms of Service, Privacy Statement, and other important information at www.ww.com/carnet. Do not drive while distracted. Vehicle features and content may vary

 Requires myW Mobile App and compatible factory—installed or dealer—installed emote start feature. See Owner's Manual for further details and important warnings about the keyless ignition feature. Do not leave vehicle unattended with the engine running, particularly in enclosed spaces, and consult local laws for any limitations on use. Standard text and data rates may apply.
- Requires myVW mobile app. Standard text and data rates may apply. See Owner's Manual for further details and important warnings about locking and unlocking your vehicle remotely Standard text and data rates may apply. Always pay careful attention to the road, and do not drive while distracted.



Warnings: See myVW in your owner's Manual for more detailed information and for important warnings.



For additional information on indicator lights, refer to your vehicle's Owner's Manual.





Lights up: ESC malfunction or ESC switched off by the system Flashes: ESC or ASR is working.



Transmission malfunction



lcy road warning. Outside temperature colder than +39 °F (+4 °C).





Anti-Lock Braking system (ABS) malfunction.



Blind Spot Monitor malfunction.



Charge level of the mobile phone battery. Applies only to models with a factoryinstalled mobile phone package.

Stop! Brake fluid level too low or brake system malfunction.

Stop! Lights up: Engine



One or more driving lights burned out. Cornering light malfunction

ABS malfunction.



Turn signals, left or right. Emergency flashers

I are Assist switched on



switched on.





Washer fluid level too low.



Fog lights switched on (indicator light on the headlight switch).



Stop! Engine oil pressure too low.

Stop! At least one vehicle door

is ajar or not closed properly.



Lights up or flashes: Engine control / Exhaust system malfunction (engine Malfunction Indicator Light - MIL).



Daytime running lights (DRL) on.



Engine control malfunction.



Lights up: Depress brake pedal! Flashes: The lock button in the selector is not engaged.



Ston! Engine bood is open or not closed properly.



Lights up or flashes: Problem



Cruise control is regulating vehicle speed / speed is stored



Stop! Trunk lid is open or not closed properly.



with the steering. Tire pressure too low or Tire

Pressure Monitoring System



Cruise control is regulating vehicle speed. Or Adaptive Cruise Control (ACC) switched on.



Stop! Lights up or flashes: Steering system malfunction.



(TPMS) malfunction. Rain / light sensor

malfunction

closed.



I are Assist switched on and ready.



Driver and/or passenger safety belts not buckled.



Fuel tank almost empty.



High heams switched on or headlight flashers in use.



Generator malfunction.



Fuel filler cap not properly



Start / Stop system is active.



Central warning light



Lights up: Engine oil level too low. Flashes: Engine oil

system malfunction.



Distance warning.



Front brake pads worn. Brake! Depress brake pedal. ACC driver intervention

warning.



Airbag and safety belt tensioner system malfunction



Adaptive Cruise Control (ACC) is switched on.

Service reminder display.



Lights up: ESC malfunction or ESC switched off by the system Flashes: ESC or ASR is working.



Passenger front airbag turned off (PASSENGER AIR BAG OFF % light).



Mobile phone is connected via Bluetooth to the factoryinstalled mobile phone package.

Failure to heed warning lights and instrument cluster text messages can cause the vehicle to break down in traffic and result in a collision and serious personal injury.

- · Never ignore warning lights or text WARNINGS.
- · Always stop the vehicle as soon as it is safe to do so.
- · Park the vehicle at a safe distance from moving traffic and where no part of the hot catalytic converter and exhaust system can come into contact with flammable materials under the vehicle, such as dry grass, brush, spilled fuel, etc.
- A broken down vehicle presents a high accident risk for itself and others. Switch on emergency flashers and set up a warning triangle to warn oncoming traffic.
- · Before opening the engine hood, always switch off the engine and let the engine cool down.
- · Always be very careful when working in the engine compartment, as it is a potentially dangerous area in any motor vehicle and can cause serious personal injury.